



INSTRUCTIONS



Materials needed: Metal Wire (provided)
Wire Cutters

Estimated Install time: 30 minutes

1. Cut 2-4 pieces of wire into 6" sections.
2. Simply loop the wire around the stock grill so the ends are facing you.
3. Repeat this step around the grill. Try to keep them in the corners and middle for the most secure hold.
4. Then place the insert grill over the ends of the wire, try to feed the wire through 2 holes next to each other and twist once for a temporary hold.
5. Repeat step 4 until you have all the wire ends through the insert.
6. Twist the wire tight up against the insert using your pliers.
7. Clip the ends of the wire about 3 winds up with your wire cutters and bend the ends into the mesh.